Work Orde		58		*753	358*						Page 1	
Revision ID: Item Name:	D412-694-015	indow		Accept	*N900	<u>040</u>	100	)* s	Setup Sta	1 /1	S1* S2*	
Required Date:		Start Qty: 2.00 Req'd Qty: 2.00	*2* *2*		Cust Item I Customer:	I <b>D</b> :						
Approvals:	Process Plan QC:	: M.L.J	Date: \\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \			ate:		F	tun Sta	DD IN	IR1* IR2*	
Sequence ID/ Work Center II		Operation Description		Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp.	
Draw Nbr	Revis	ion Nbr									<u> </u>	
N/A	Rev N	I/A									٨	
*1 \\n\* DC  Document Control	, , , , , , , , , , , , , , , , , , ,	DOCUMENT CONTRO Memo Photocopy I	•	0.00 0.00 per PPP D412-694-015 C	CHG002			2	J Cor	MLI	W 12.06. 12-6-11 2	ادر
110 *110*		Pick Kit		0.00					/~12	s [e/u_	( <del>)</del>	
Packaging Packaging		Memo		0.00						,		
*120		QC4- 100% Inspect kits	for completeness	0.00				_2			N 12:02 1	1
QC		Memo		0.00							· ·	

Quality Control

Dart	Aer	OS	pác	e l	_td

Dail Mei	ospace	; Llu							•						
W/O:		WORK ORDER CHANGES													
DATE	STEP	PR	OCEDURE CHA	NGE	Ву	Date	Qty	Approval * Chief Eng / Prod Mgr	Approval QC Inspector						
	1														
	:														
Part No		PAR #:	Fault Cate	gory:	NCR: Yes	No DQA	:	Date:	· · · · · ·						
_	R	esolution:	Dispositio	n:	QA: N/C Clo	sed:		Date: _							
NCR:			WORK ORD	ER NON-CONFORMAN	ICE (NCR	)									
		Description of NC		Corrective Action Section	В	Verifica	ation	Approval	Approval						
DATE	STEP	Section A	Initial Chief Eng	Action Description Chief Eng	Sign & Date	Sectio		Chief Eng	QC Inspector						
							!								
	1					·									

NOTE: Date & initial all entries

•	<b>Work Order ID 75358</b> <i>Qctober-21-11 8:11:42 AM</i>			*75358*									
Item ID: D412-694-015  Revision ID:  Item Name: Replacement Window			4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	Accept	14.51.11.11.11.11					Start Stop	14.21		
	20/10/2011	Start Qty: 2.00 Req'd Qty: 2.00	*2* *2*		Cust Item II Customer:	<b>)</b> :				зюр	*N:	S2*	
Approvals:	Process Pla	n:	Date:	Tooling:	Da	te:	_	R		Start	*NI	R1*	
	QC:		Date:	SPC (Y/N):	Da	te:				Stop	*NI	R2*	
Sequence ID/ Work Center ID	)	Operation Description		Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Rejec Qty		Reject Number	Insp. Stamp	
*130*		Packaging							/	/ 6		(B) (3	
Packaging Packaging		Memo Identify and 015Location	pack for shipping as per	0.00 PPP D412-694-						<i>v</i>	J.J.		
140		QC21- Final Inspection -	Work Order Release	0.00							1. 1.	$A \sim A$	
*140* QC Quality Control		Memo		0.00						121	16/10	10012	

MUS 12106112

_	•	-		~	-	-	-	-	-		1 4	-	
	7		-	er				71		-	1 1		
_	~	•	,	v.	•	•	~	•	•	•	_	•	

W/O:			V	VORK ORDER CHANGES		······································			
DATE	STEP	PRO	CEDURE CH	IANGE	Ву	Date	Qty	Approval * Chief Eng / Prod Mgr	Approval QC Inspector
									•
		·		· · · · · · · · · · · · · · · · · · ·		·····			
Part No	:	PAR #:	Fault Ca	tegory: N	ICR: Yes	No <b>DQ</b>	A:	Date:	-
	R	esolution:	Disposit	tion: C	A: N/C C	Closed:		Date: _	
NCR:		V	VORK OR	DER NON-CONFORMANO	CE (NC	R)			
DATE	STEP	Description of NC		Corrective Action Section B			cation	Approval	Approval
DAIL		Section A	Initial Chief Eng	Action Description Chief Eng	Sign Date		ion C	Chief Eng	QC Inspector
		,			·				
	1								
	*								
-									
					,				
				,			<del></del>		

NOTE: Date & initial all entries

 Location
 Loc Oty
 Loc Code

 ST214
 6
 6

 74430
 6
 5

 ST215
 2
 6

 64892
 2
 6

	Dar	t Aer	ospa	ce	Ltd
--	-----	-------	------	----	-----

	7 7 7 7														
W/O:			WORK ORDER CHANGES												
DATE	STEP		PROCEDURE CH	ANGE		Ву	Date	Qty	Approval * Chief Eng / Prod Mgr	Approval QC Inspector					
					•										
		·						٠.							
Part No	:	PAR #:	Fault Ca	tegory:	_ NCR	: Yes N	o DQA	۸:	_ Date: _						
	į	Resolution:	Disposit	ion:	QA:	N/C Clos	sed:		Date:						
NCR:			WORK OR	DER NON-CONFORM	ANCE	(NCR)									
DATE	STEF	Description of NC		<del></del>	tion B		Verific	ation	Approval	Approval					
DATE	SIEF	Section A	Initial Chief Eng	Action Description Chief Eng		Sign & Date	Section	on C	Chief Eng	QC Inspector					
			***		i.	3									
								;							
		·													

NOTE: Date & initial all entries

#### 6. PARTS LIST

Qty -011	Qty -013	_Qty_ \ -015	Qty -017	Qty -01	Qty -02	Qty -03	Qty -04	Part Number	Description
X								D412-694-011	SPACEDOOR™ INSTALLATION
	Х							D412-694-013	PANEL INSTALLATION (OPTIONAL)
4		Х						D412-694-015	REPLACEMENT WINDOW KIT
			X					D412-694-017	BEARING OVERHAUL KIT
1				X.				D412-694-01	DOOR ASSEMBLY
1					Х			D412-694-02	DOOR ASSEMBLY
1						X		D412-694-03	DOOR ASSEMBLY
1							Х	D412-694-04	DOOR ASSEMBLY
						l		***	
2 .								D2126-0730	SEAL
4	<u> </u>							D3090-1	SHIM
4								D3090-3	SHIM
2								D3108-1	DECAL
2								D3108-2	DECAL
4					i			D3108-3	DECAL
4								D3108-5	DECAL
2								D3108-7	DECAL
						1	1	D3110-1	ESCUTCHEON
						1	1	D3110-3	HANDLE .
				1	1			D3110-5	HANDLE ASSEMBLY
						1	1	D3111-041	PLATE ASSEMBLY
						2	2	D3112-1	GUIDE
						1	1	D3113-1	SPRING
						1	1	D3114-1	PIVOT
				1	1			D3115-1	BRACKET
2						İ		D3116-1-0500	SEAL
						1	1	D3116-11-0180	SEAL
2								D3116-3-0500	SEAL
						1	1	D3116-5-0680	SEAL
				1	1			D3116-7-0680	SEAL
				1	1			D3116-9-0770	SEAL
		1						D3117-1-0980	SEAL RETAINER
		1						D3117-3-0980	SEAL FILLER L
4								D3118-3	SIGN ASSEMBLY
4								D3118-5	SIGN ASSEMBLY
				L		1		D3119-041	COVER ASSEMBLY
							1	D3119-042	COVER ASSEMBLY
						1		D3120-1	COVER
							1	D3120-2	COVER
						1		D3120-3	COVER
							1	D3120-4	COVER
				3	3			D3121-041	BRACKET ASSEMBLY ("ROLLER")
				1				D3121-043	BRACKET ASSEMBLY ("ROLLER")
				Ĭ	1			D3121-044	BRACKET ASSEMBLY ("ROLLER")
			7					D3121-21	SCREW

COPYRIGHT © 2002 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **B** 



## DART AEROSPACE LTD.

IIN-D412-694

Page 16 of 18

	Qty -013	Qty ∫-015	Qty -017	Qty -01	Qty -02	Qty -03	Qty -04	Part Number	Description
			5					D3121-241	BEARING ASSEMBLY
				1	1			D3122-1	LEVER
		,		2	2			D3123-1	CAM
				1	1			D3124-1	HOOK
				1	1	ĺ		D3124-2	HOOK
						1	1	D3125-1	LEVER
						1	1	D3125-3	LEVER
						1	1	D3125-5	LEVER
						1	1	D3125-7	LEVER
				1	1	ĺ		D3126-1	BRACKET ("SLIDER")
				1	1	Ì		D3126-3	BRACKET ("SLIDER")
				5	5			D3126-5	BRACKET ("SLIDER")
				1	1			D3127-1	SPACER
						1	1	D3128-1	SHIM
						2	2	D3129-1	LEVER
			•			2	2	D3130-1	CLEVIS BASE
						1	1	D3131-1	STOP
				1				D3132-041	ROD WELDMENT
					1			D3132-042	ROD WELDMENT
	-				1			D3133-041	ROD WELDMENT
			-	1			İ	D3133-042	ROD WELDMENT
						1	1	D3134-1	ROD
						1	1	D3134-3	ROD
<b>-</b>				1	1	<del></del>	<del>                                     </del>	D3135-041	HANDLE WELDMENT
-		1	į	<del></del>				D3136-041	WINDOW ASSEMBLY
				2	<u> </u>			D3137-041	BRACKET ASSEMBLY ("ROLLER")
			1					D3137-3	GUIDE
			1					D3137-5	WASHER
				1				D3138-1	COVER
				·	1			D3138-2	COVER
				1	1			D3139-1	GUARD
				1				D3139-3	GUARD
			-		1			D3139-4	GUARD
				1				D3140-05	DOOR
				l	1			D3140-06	DOOR
						1	<b>—</b>	D3140-07	DOOR
							1	D3140-08	DOOR
		<b></b>		2	2		<del>                                     </del>	D3141-1	SPRING
	-			<del></del>	<u> </u>	1	1	D3143-1	CLEVIS
				,	<b></b>	3	3	D3143-3	CLEVIS
					-	1	Ť	D3144-1	DOUBLER
				<u> </u>		1		D3144-105	DOUBLER
				· · · · · · · · · · · · · · · · · · ·		1		D3144-107	DOUBLER
-	<del></del>	-		1	<del></del>	<del>                                     </del>		D3144-109	DOUBLER
	<del> </del>			1	1			D3144-111	DOUBLER
	<b>.</b>			<del> </del>	1	<del>                                     </del>		D3144-115	DOUBLER
	<del> </del>	<del> </del>		<del> </del>	<del>'</del>		1	D3144-117	DOUBLER
		<del>   </del>		f <del></del>	<del>                                     </del>	<del>                                     </del>	1	D3144-119	DOUBLER

• COPYRIGHT © 2002 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **B** 

# REFERENCE ONLY

#### DART AEROSPACE LTD.

IIN-D412-694

Page 17 of 18

Qty -011	Qty -013	Qty- /-015/	Qty -017	Qty -01	Qty -02	Qty -03	Qty -04	Part Number	Description
							1	D3144-121	DOUBLER
				-	1			D3144-123	DOUBLER
				1	1			D3144-13	DOUBLER
				1				D3144-3	DOUBLER
	<del>                                     </del>					1		D3145-1	HINGE BRACKET
						,	1	D3145-2	HINGE BRACKET
	<u> </u>					1		D3146-1	HINGE BRACKET
	<del>                                     </del>						1	D3146-2	HINGE BRACKET
	<del> </del>	1				2	2	D3147-1	PIN
	-	1		2	2			D3148-1	CLEVIS
	├					2	2	D3149-1	STRIKER PLATE
	<del> </del>			<u> </u>		2	2	D3150-1	GUIDE
	<del> </del>	$\vdash$		1	1	<del>  =</del>	<del>-</del>	D3151-041	DOUBLER ASSEMBLY
	<del>                                     </del>	<u> </u>		1		<u> </u>		D3152-041	BRACKET ASSEMBLY
	├─			<u>'</u> -	1			D3152-042	BRACKET ASSEMBLY
	1			ļ	<del></del>	<del></del>	<u> </u>	D3153-11	PANEL
	1 1	<del> </del>		-				D3153-12	PANEL
	<del>                                     </del>							D3153-13	PANEL
		<b>-</b>				<del>                                     </del>	1	D3153-14	PANEL
	1							D3153-15	PANEL
	1 1				<u> </u>			D3153-15	PANEL
	1					1	1	D3154-1	KEY
	<u> </u>	<u> </u>				1_	<del>  '</del>	D3155-041	BRACKET ASSEMBLY
	-			1	1		-	D3155-041	BRACKET ASSEMBLY
	ļ			1	1	<u> </u>		<del></del>	BRACKET
		ļ		2	2	<del>  </del>	<u> </u>	D3156-1	SPACER
	<u> </u>					2	3	D3157-1 D3159-041	BRACKET ASSEMBLY
	ļ					3	3		BRACKET ASSEMBLY
					ļ	1_		D3159-043	BRACKET ASSEMBLY
-,-				1.0	12		1	D3159-044	
				12	12			D3162-041	BRACKET ASSEMBLY
				1		ļ	ļ	D3163-041	COVER ASSEMBLY COVER ASSEMBLY
				<u> </u>	1	ļ	ļ <u>.</u>	D3163-042	
				1			ļ	D3183-041	BRACKET ASSEMBLY ("ROLLER")
					1	ļ	ļ	D3183-042	BRACKET ASSEMBLY ("ROLLER")
			2				ļ	D3183-045	BEARING ASSEMBLY
				1	1		ļ	D3203-1	HANDLE ASSEMBLY
2				<u> </u>		<u> </u>		D3300-1	WINDOW
				2	2		<u> </u>	D3308-1	DOUBLER
				55_	55	21	21	80-005-2-8	INSERT (OR SL2052-3-4)
	60							A6K75	RIVNUT
				10	10			AN525-10R6	SCREW
	1			8	8	4	4	AN525-10R7	SCREW
	1	1				8	8	AN960JD10	WASHER
	1		l	18	18	4	4	AN960JD10L	WASHER
	<del>                                     </del>			13	13	32	32	AN960JD10LL	WASHER
		†	t	6	6			ANS60JD416L	WASHER
	1	<del>  -</del>	<del>                                     </del>	<del>                                     </del>	†	4	4	AN960JD6L	WASHER
	<del>                                     </del>		<del>                                     </del>	6	6	<del>†                                      </del>	† - ·	AN960JD8	WASHER
	+	<del> </del>	<del>                                     </del>	┼ <u></u>	t -	2	2	AN960JD8L	WASHER

COPYRIGHT © 2002 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **B** 

# REFERENCE ONLY

## DART AEROSPACE LTD.

IIN-D412-694

Page 18 of 18

Qty -011	Qty -013	Qty_ -015	Qty -017	Qty -01	Qty -02	Qty -03	Qty -04	Part Number	Description
						2	2	AN960JD8LL	WASHER
						10	10	ASL4-632-80	INSERT
				87	87	47	47	BSP45	RIVET
						14	14	FW10-032	WASHER
						6	6	FW4-032	WASHER
				12	12			M7885/2-4	RIVET (OR CR3213-4-3)
						3	3	M7885/3-4	RIVET (OR CR3212-4-3)
						2	2	MS20392-1C11	PIN
						5	5	MS20392-2C15	PIN
				2	2			MS20392-2C17	PIN
				2	2	2	2	MS20392-2C9	PIN
				2	2			MS20392-3C21	PIN
				8	8			MS20426AD3	RIVET
				20	20			MS20426AD4	RIVET
				A/R	A/R			MS20995-C20	LOCKWIRE
						6	6	MS21042L06	NUT
				6	6	2	2	MS21042L08	NUT
						5	5	MS21042L3	NUT
				4	4			MS21042L4	NUT
				4	4			MS21072-L3	NUTPLATE
	ļ			6	6	9	9	MS24665-151	COTTER PIN
				4	4			MS24693-S271	SCREW
						2	2	MS24694-C4	SCREW
			_	4	4			MS24694-C5	SCREW
			1					MS24694-S101	SCREW
				6	6			MS24694-S5	SCREW
				18_	18			MS24694-S50	SCREW
						4	4	MS24694-S56	SCREW
						2	2	MS24694-S6	SCREW
						4	4	MS24694-S60	SCREW
				4	4			MS24694-S98	SCREW
						2	2	MS25281-R6	CLAMP
				2	2	2	2	MS27039-1-05	SCREW
				14	14	12	12	MS27039-1-06	SCREW
				13	13	6	6	MS27039-1-08	SCREW
						2	2	MS35206-231	SCREW
	ļ	ļ		2	2	ļ	ļ	MS35275-233	SCREW
	ļ			2	2		<b> </b>	MS35649-264	NUT
						4	4	MS35650-305T	NUT
		ļ <u>.</u>		2	2	ļ	L	MS35650-3252	NUT
				2_	2	3	3	MS51859-7	WASHER
						4	4	NAS1169-10L	WASHER
						1	1	NAS388-6-12P	SCREW
	60					14	14	NAS388-6-8P	SCREW
	60					15	15	NAS391B6P	WASHER
				7	7			NAS43DD3-10	SPACER
				6	6			NAS43DD3-14	SPACER
						2	2	NAS43DD3-40	SPACER

COPYRIGHT © 2002 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **B**